












**Produktfamilj**  
**Honeywell V-Maxx**

A sporty style goggle for increased wearer acceptance. Fits a wide variety of workers and can be worn over prescription eyewear and with most half-mask respirators.

**Honeywell**

**Product Numbers &**

	1006195	<b>Closed Vent,Elastic Headband</b> Clear Body, Clear Polycarbonate Lens, Fog-Ban Anti-fog Coating
	1006194	<b>Indirect Vent,Neoprene Headband</b> Clear Body, Clear Polycarbonate Lens, Fog-Ban Anti-fog Coating
	1008110	<b>Indirect Vent,Elastic Headband</b> Black Body, IR/PC 3.0 Lens, Anti-scratch Coating
	1006192	<b>Indirect Vent,Elastic Headband</b> Clear Body, Clear Polycarbonate Lens, Anti-scratch Coating
	1006193	<b>Indirect Vent,Elastic Headband</b> Clear Body, Clear Polycarbonate Lens, Fog-Ban Anti-fog Coating
	1006196	<b>Closed Vent,Foam Elastic Headband</b> Clear Body, Clear Polycarbonate Lens, Fog-Ban Anti-fog Coating
	1006437	<b>Peel-off Goggle Covers</b> 10 Pack

	1007506	<b>Indirect Vent, Neoprene Headband</b> Clear Body, Clear Acetate Lens, Fog-Ban Anti-fog Coating
	1008111	<b>Indirect Vent, Elastic Headband</b> Black Body, IR/PC 5.0 Lens, Anti-scratch Coating

## Översikt

### Viktigaste egenskaperna

- Sleek wrap-around styling for a 180 degree, clear field of vision
- Direct and indirect ventilation styles available for impact or splash applications
- Adjustable elastic or neoprene headband
- Pivoting headband clips to adjust strap around hard hats or hearing protection
- Peel-off goggle covers available to extend useful life of the lens
- Can be worn over most prescription eyewear (OTG compatible)
- Available in 3.0 and 5.0 welding shades
- Available with scratch-resistant hardcoating or optional Fog-Ban anti-fog coating

### Rekommenderade branscher/rekommenderat användningsområde

- Kemi
- Byggingusti
- Tillverkning
- Svetsning

### Risker

- Nötning
- Luftburna partiklar
- Biologiska risker
- Kemi
- Gas, ånga, rök
- Stöt
- Dålig sikt
- Stänk

### Föreskrifter

- ANSI Z87+ - ANSI Z87+ (High Impact) standard
- ANSI Z87.1-1989/CA 21,194 - Meets ANSI Z87.1-1989/CA 21,194 (MTE Link [http://www.mte.gov.br/Empregador/segsau/Pesquisa/CA\\_DET.asp?vNRCAProc=21194&Equipamento=00&NOEquipamento=&Fabricante=00&NOFabricante=](http://www.mte.gov.br/Empregador/segsau/Pesquisa/CA_DET.asp?vNRCAProc=21194&Equipamento=00&NOEquipamento=&Fabricante=00&NOFabricante=))
- CSA Z94.3 - Tested by Honeywell to meet the requirements of the CSA Z94.3 standard
- EC Category PPE, Standards EN 166/EN 175, European Directives 89/686/EEC, ISO 9001/2000, Optical Class I, Impact Grade B (High speed particles, medium energy) and F (High speed particles, low energy), 3 (protection against splashes of liquid), 4 (protection against large dust particles), 5 (protection against gases and fine dust particles), 9 (protection against molten metals and hot solids)

### Tidigare varumärke

Pulsafe, Willson

### Garantiinformation

LIMITED WARRANTY: Honeywell warrants that its products are free from defects in material and workmanship. A product that is subject of a warranty claim must first be made available to an authorized Honeywell Safety Product distributor or the to seller from whom the product was purchased. All warranty returns must be shipped pre-paid. Honeywell or the Honeywell Safety Product distributor will then determine whether repair or replacement of the product is the appropriate remedy. This will be done at no charge to the end-user. This limited warranty does not cover any Honeywell product or component found to have been altered, misused, abused tampered with or improperly maintained or to have deteriorated due to aging of any components made of rubber or any other elastomer. This limited warranty does not cover any damage, loss or expense due to damage caused by accident, abuse, improper maintenance, use or misuse of the product. Honeywell Safety Product should be used only on strict accordance with and adherence to the detailed instructions and warnings provided with the product.

## Specifikationer

### Lens Material

- Polycarbonate & Acetate

### Lens Overall Width

- 170mm

**Lens Material**

- Polycarbonate

**Lens Coating**

- Fog-Ban® anti-fog coating, Hardcoat

**Lens Thickness**

- 2.1mm

**Available Lens Tints**

- Clear, IR/PC 3.0

**Replacement Lenses Available (Yes/No)**

- No

**Rx Capable**

- Can be worn over most prescription eyewear

**Goggle Weight**

- 101 grams

**Goggle Body**

- Polyurethane

**Available Headband Material**

- Neoprene or Elastic Headband

**Available Headband Colors**

- Black, Red

**Dielectric Frame (Yes/No)**

- Yes

**Packaging**

- 1/polybag, 10 pr./stocker, 200 pr./case or 10 pr./polybag

**Country of Origin**

- China

**Side Shield Material**

- N/A

**MSDS Requirements**

- None

**WHMIS Requirements**

- None

**Harmonization Code**

- 9004.90.0000

**Ventilation**

- Indirect & No Vent

**Lens Protectors**

- Available

**Trycksaker & dokument**

Data Sheet Sperian V-Maxx Goggle\_Eng

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Eye\\_and\\_Face\\_Protection/Goggles/19087/1033.aspx](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Goggles/19087/1033.aspx)

**Training & Proper Use**

All products come packaged with instructions and warnings for proper use.

## Teknisk support

France : [info-france.hsp@honeywell.com](mailto:info-france.hsp@honeywell.com)

Export : [info-export.hsp@honeywell.com](mailto:info-export.hsp@honeywell.com)

Belgium, Luxembourg, netherlands : [info-benelux.hsp@honeywell.com](mailto:info-benelux.hsp@honeywell.com)

Germany, Austria, Switzerland : [info-germany.hsp@honeywell.com](mailto:info-germany.hsp@honeywell.com)

Italy : [info-italia.hsp@honeywell.com](mailto:info-italia.hsp@honeywell.com)

United Kingdom, Middle East & SouthernAfricaBranch : [info-uk.hsp@honeywell.com](mailto:info-uk.hsp@honeywell.com)

Spain, Portugal : [info-spain.hsp@honeywell.com](mailto:info-spain.hsp@honeywell.com)

Sweden, Denmark, Finland, Iceland, Norway : [info-nordic.hsp@honeywell.com](mailto:info-nordic.hsp@honeywell.com)

Estonia, Latvia, Lithuania : [info-nordic.hsp@honeywell.com](mailto:info-nordic.hsp@honeywell.com)

Russia : [info-russia.hsp@honeywell.com](mailto:info-russia.hsp@honeywell.com)

Hungary : [info-hungary.hsp@honeywell.com](mailto:info-hungary.hsp@honeywell.com)

Poland : [info-poland.hsp@honeywell.com](mailto:info-poland.hsp@honeywell.com)

## RELATERADE PRODUKTER